

Marking your Feet

Marking your Curve Master Foot

The Curve Master has a 'wall' that juts out on the right side. Use a red Sharpie or red finger nail polish to highlight it. This will help your eyes to focus on it rather than the needle when you're sewing.

As you sew, you'll line your fabric right next to this wall, allowing you to sew a straight or curved $\frac{1}{4}$ " or scant $1\frac{1}{4}$ " seam.



Watch my video to see more about this!


<http://www.winnerdesigns.com/stitch-in-the-ditch-curve-master/>

Marking your Stitch in the Ditch Binding Foot (SND)

The SND foot has markings showing $\frac{1}{4}$ " to almost 1" seam allowances plus numbers depicting each fence. Use a black Sharpie & color in these markings.

1. Color the #s on each Fence
2. Color the seam allowance markings on the Foot
3. If you always use the same width of binding & seam allowance, you can draw a line on the foot that to mark your seam allowance. When you are getting close to an edge, this line will let you know to stop sewing. Place the Foot with no Fence on your machine and lower the presser foot and the needle. Use a hem marking ruler and measure out $\frac{1}{4}$ ", $\frac{3}{8}$ " or $\frac{1}{2}$ " from the needle and make a mark on the foot.

Take the foot off the machine. Draw a horizontal line across the foot where your mark is to designate your seam allowance.



Note: Hairspray works great to remove any excess Sharpie ink!

Watch my videos to see more about this. And to make this clear, in the Part 1 video, you'll see me using a Sharpie and hair spray to mark my foot.

<http://www.winnerdesigns.com/banish-bad-bindings-class/>

<http://www.winnerdesigns.com/stitch-in-the-ditch-curve-master/>